Directional Buoy

Art. No. 1310017

Suitable for water events such as Open Water Swimming and Triathlon.

Our buoys increase visibility by making it easier for participants to keep direction and avoid swimming towards dangerous waters or losing their way.

Streamline your swimming events with our directional buoys, designed to connect finish funnels or guide swimmers along the course between turning buoys. These markers help maintain clear lanes, ensuring smooth, safe, and professional competition environments.

Possibility to affix advertising banner as the buoy is equipped with eyelets for affixing. Banner is not included. Great way to brand your event, over-sized with wide advertising spaces that can be used for promotion.

Available in vibrant Yellow and Red, these markers not only enhance visibility in the water but also add a pop of color to your event.

Yellow are used as directional buoys and Red are used to mark the beginning of the goal funnel.

Main Features

- High visibility
- Easy to use, inflate and deflate
- Advertising possibility

Product Information

Material: PVC Tarpaulin
Dimensions when inflated:
Height: 150 cm **Diameter:** 150 cm
Inflates and deflates in approx.
5 -10 minutes depending on pump
Colors: Yellow or Red
Material: PVC Tarpaulin
Sold per unit

Please Note: Supplementary products, Pump, Rope, Snap Hooks **sold separately**

Delivery Time: 6-8 weeks
Sold per unit

Selected When it Counts

Malmsten AB • www.malmsten.com
+46 44 28 71 00 • info@malmsten.com

Malmsten

Directional Buoy - Useful Information

Directional Buoy Height: 150 cm, Diameter: 150 cm (when inflated)
Prefitted eyelets for affixing advertising banner. We recommend small reinforced holes on banner.

The following accessories are needed to maintain position of the buoys. (Sold separately)

- To inflate or deflate use a pump. Buoys must be out of the water. Attention: Electric pump sold separately
- Snap Hooks
- Ropes
- Anchors (Be sure to anchor from at least 4 of the bottom hooks of the buoys to avoid ripping)

Inflating/Deflating Instructions and Maintence

For a long and successful product life, handle with care.

Be careful when opening new box as a cutting knife may damage the inflatable unit.

Also be aware that sharp corners or dragging on pool deck may damage the unit.

After use, rinse off the unit with clear tap water and let air dry before placing back in storage bag.

Please Note: Be careful when opening storage bags and handling the equipment.

A cutting knife, sharp corners or dragging on ground or beach will damage the unit.

To inflate:

1. Unscrew the plug
2. Attach pump and inflate. It will take about 5- 10 minutes.
3. When finished - screw the plug back on

Please Note: Do not over-inflate as it can damage the buoy beyond repair. Keep air outlet clear of dirt and debris as this may cause air to leak out of the the outlet.

- Place advertisement banners once inflated
- Place buoy in the water
- When finished using - carefully remove from the water.

Please note, any sharp edge may damage the PVC. Rinse with clean water and let air dry.

- Once fully dried - deflate unit

To deflate:

1. Unscrew the plug
2. Use the “air-intake” side on the pump to deflate
3. Clean unit with clean water. Remove dirt and let air dry.

Please Note: Check for dirt and debris in and aroud the air outlet, clean thoroughly before storage.

- To fit back into storage bag, it is crucial to tightly roll and fold the buoy. (Once buoy is completely dry)
- In case of air leakage through a small hole - wipe area dry and affix repair sheet (not included) with suitable glue for PVC (not included).

Malmsten AB • www.malmsten.com
+46 44 28 71 00 • info@malmsten.com